



How to take the correct measures for Petrie's riding boots so that optimum comfort and a good fit is achieved.

Please follow directions carefully, and get a friend to help

1. Leg height (measure standing)

At the outside of the leg from the ground to the splintbone knob and at the back from the ground highly into the hollow of the knee (top knob - top hollow of the knee). If you have a pair of boots you love, and are the correct length, it is also worth double checking by measuring up the back from the heel to the top of the boot.

CAUTION! These two measures must be equal, otherwise they are not taken correctly





2. Crook of knee (measure sitting)

Measure in the hollow of the knee off the splint bone knob (top knob - top hollow of the knee).

CAUTION! Both legs must be placed right-angled and loosely on the ground



3, 4 & 5 . Calf outline & leg measurements (measure sitting)

Measure the thickest outline of the calf – don't pull the tape too tight!

You should also let us know what height from the floor the calf outline is. You will need to take measurements at 10cm, 15cm, 20cm, 25cm and 30cm, and then measure the widest part of the calf, and make a note next to calf outline what height the calf is at its widest. This is typically 10 – 12cm below the height measurement.



CAUTION! Both legs must be placed right-angled and loosely on the ground

**6. Heel 7. Instep /8. Ball
(measure standing)**

Take the three outline measures – as shown on the pictures with loosely laid measuring tape.

